

Power Supply Powered by an External Timer

This mode is intended for operation when the PS is connected to a Programmable Wall Outlet Timer Switch.

The objective is that the robot will operate according to the timing programmed in the wall outlet.

Activation:



Step 1

Plug the PS to a wall outlet.

Step 2 & 3

While the PS is OFF, press and hold the "Weekly Timer" button, till the three LEDs flash for about 5 seconds.

Step 4

Unplug the PS, then plug again to the wall outlet. The PS will switch ON automatically, within several seconds.

Notes:

- Please, pay attention to program the Wall Outlet Timer for a minimum period equivalent to the duration of the robot's cycle time.
- To deactivate this special Programmable mode, please repeat the above procedure.
- Once activated in this *Timer mode*, the cleaner will operate each and every time the Timer is ON (This means that if the Timer is programmed to ON twice or more per day, the cleaner will operate accordingly, twice or more, at the same time).
- Once activated in this *Timer mode*, any programming of the PS, either using the PS-keypad or using MyDolphin application, will be lost at the first electricity switch off.